

Determining renewable data blocks & creating "DBLMgr.dbl"-container via DBL Manager

1 Click "HenriDBLMgr"-icon on your desktop, to start DBL Manager.



2 Click on ECV whose data blocks you may want to update, from list inside DBL Managers main window.




fig.1: DBL Manager - main window

3 Click "+"-button, to open overview of available data blocks, for chosen ECV. (s. fig.: 1)

4 Select data blocks, you may want to update from open-data block-dialog.

Pick multiple data blocks sequently, by holding down "Strg"-button while selecting.




fig.2: Picking multiple data blocks

5 Click open button from open-data block-dialog. (s. fig.: 2)

Note: Selected data blocks now appear below specific ECV. Repeat steps 2-5 for all of your ECV devices.

When done with configuring your data block-set for each needed ECV, follow step no. 6.

6 Click "save"-button, to store a "DBLMgr.cfg" to a preferred location on your computer. (s. fig.: 3)

2

Transferring DBLMgr.dbl to Henri+-service-tool via DBL Manager

7 Click "create"-button, to let DBL Manager create "DBLMgr.dbl" file.

Note: "DBLMgr.dbl" will be stored in same directory as "DBLMgr.cfg".





fig.3: Save-button is available, after data blocks have been chosen.

8 Click "transfer"-button.



DBL Manager will now transfer the configured data block-container "DBLMgr.cfg" to HENRI+.



9 Click "end"-button to end HENRI+-update procedure.

You have now transferred DBLMgr.dbl to HENRI+-service-tool via DBL Manager!

Transferring DBLMgr.dbl via DBL Manager - Troubleshooting

In case DBL Manager puts out a "failed" alert-message (fig.4):




fig.4: Transfer failed, (re-) connect HENRI+ to computer

- 1 Check for proper USB-connection between HENRI+-service-tool and your computer.
- 2 Click "transfer"-button again, to restart transfer process, to now proper connected HENRI+-service-tool.

HENRI+ SERVICE MANUAL

Transferring data via Windows Explorer

- 1 Connect HENRI+-service-tool to a computer. (Described in chapter: "Connecting Henri+-service-tool to a computer")



HENRI+ is now ready, for communicating with your computer. It shows in Windows Explorer as mass storage device ("E:").




fig.1: HENRI+ showing in Windows Explorer

- 2 Repeat steps 1-7 from chapter: "Determining renewable data blocks, creating container "DBLMgr.dbl" via DBL Manager".




Note: "DBLMgr.dbl" will be stored in same path as "DBLMgr.cfg".

- 3 Rename "DBLMgr.dbl" into "data.dbl".
- 4 Open Windows Explorer.
- 5 Navigate to renamed "data.dbl" destination path.
- 6 Open a second Windows Explorer window.
- 7 In your second Windows Explorer, navigate to mass storage device HENRI (E:). Open it.
- 8 Drag and drop "data.dbl" from your storage folder onto HENRI+-service-tool.



Note: You're might being asked to replace "data.dbl", since it is already existing on HENRI+-service-tool. In that case choose "Yes" from replacement-dialog, in order to apply your new configured container to your device.



4

HENRI+ SERVICE MANUAL

Necessary hard- and software for a HENRI+ data block update

In order to update a HENRI+ device in terms of data blocks you will need:

- HENRI+-Service-Tool
- USB 2.0 - to mini-USB-cable for communication between HENRI+ and a computer.
- DBL Manager v.1.0 or higher.
- Data block-container DBLMgr.dbl, containing customized set of coin validator-data blocks.

Connecting Henri+-service-tool to a computer



fig.1: Connecting USB cable to HENRI+

- 1 Connect mini-USB-cable with mini-USB-interface on bottom of HENRI+ tool.
- 2 Press and hold! -button, then connect mini-USB-cable to your computer.



Keep -button pressed, until Henri+ message appears:



HENRI+ is now ready, for communicating with your computer.

01/12 IGr/Eck/KQu
Version 1.0
SA_DBLMgr_EN

1